

# Vertical Turbine, Wet-Pit Pump

Product Lubrication, Standard Construction

# **Open Lineshaft Construction**

Allows lineshaft bearings to be lubricated by the pumped fluid.

# **Externally Sourced Prelubrication Connection**

(Optional, not shown) Prevents dry running the lineshaft bearings on deep set applications by lubricating them prior to start-up.

## Cast Discharge Head

Smoothly transitions fluids into the discharge piping. Cast ANSI 125# or 250# flat face flanges. Also functions as a mounting base for the driver.

# **Bearing Retainer With Rubber Lineshaft Bearing**

Provides shaft support and maintains alignment. Retainers are spaced between column sections. Rubber lineshaft bearings include a stainless steel sleeve.

## **Enclosed Impellers**

Cast to provide smooth passageways for more efficient fluid flow. Semi-open impeller designs available on certain models.

## **Drive Collets**

Provide an interference fit between the bowl shaft and impeller to hold the impeller securely in place.

#### **Suction Bell**

Provides efficient flow into the eye of the first stage impeller. A suction case is provided for deep well pump applications.

# **Basket Strainer**

Prevents debris from entering the pump. Conical strainer available for deep well pump applications.

#### **Vertical Hollow Shaft Motor**

Allows the pump headshaft to extend through the motor. Provides impeller clearance adjustment with an adjusting nut located at the top of the motor. A two-piece headshaft with a motor stand is available for low overhead sites.

# Stuffing Box

Accommodates low and high pressure stuffing box or mechanical seal arrangements with piping plans. Provided with hard bearing below sealing arrange ment for rigid support.

# Threaded Lineshaft Coupling

Positively locks lineshaft sections together for low torque applications.

## **Threaded Column Assembly**

Maintains alignment of the pressure retaining column sections through precision machined threaded pipe couplings. Minimizes well pump casing diameter. Available on column sizes 100 mm (4 in) to 355 mm (14 in).

## **Bowl Adapter**

Ensures efficient transfer of flow from bowl assembly to various column sizes.

## Bowl and Bell Bearings

High length-to-diameter ratios provide rigid shaft support in the bowl assembly.

### Sand Collar

Prevents grit from entering the suction bell bearing.

### Grease Plug

Allows suction bell bearing to be permanently grease packed for long life and maximum reliability.



Europe, Middle East, Africa
Flowserve Corporation
Parallelweg 13
4878 AH Etten-Leur
The Netherlands
Telephone: +31 76 502 8100

Latin America
Flowserve Corporation
Martín Rodriguez 4460
B1644CGN-Victoria-San Fernando
Buenos Aires, Argentina
Telephone: +54 11 4006 8700
Telefax: +54 11 4714 1610

Asia Pacific
Flowserve Pte. Ltd.
10 Tuas Loop
Singapore 637345
Telephone: +65 6771 06
Telefax: +65 6862 2329

VTP Design Center Flowserve Corporation 5310 Taneytown Pike Taneytown, MD 21787

**FPD-1140a (E)** Printed in USA. February 2011. © Flowserve Corporation

**USA** and Canada

Flowserve Corporation

5215 North O'Connor Blvd.